

# INSTRUCTIONS FOR GENERATORS/LIGHT TOWERS

The generators can only support a device less than 10 amps maximum draw. **DO NOT** plug anything into the generators of the light towers. If you do you will blow the fuses in the tower and the lights must cool before they can be restarted.

## LIGHT TOWER INSTRUCTIONS:

1. Park and set light tower in a flat area.
2. Use screw jacks on corners to level if necessary
3. Adjust the lights to project into the desired area/direction
4. Raise the lights into place by removing locking pins at mast and crank the cable handle to raise mast.
5. Be sure all switches for lights are in the **OFF** position before starting motor.
6. Start motor
7. Once motor is started light switches can be flipped on. Allow time for lights to warm up for maximum intensity.

To Shut down lights and generators:

1. Unplug battery charger if using
2. Turn light switches to off position.
3. Turn generator motor off
4. Lower the light mast

### **Special note:**

**Pay attention to the light mast in strong winds. It may be necessary to lower the mast to prevent damage to the unit.**